
Cap
6′-0"
Min
6′-0"
Min
Column
Crash Wall
Foundation (bottom of footings, when used, shall be at or below the bottom of the crash wall).

Fig. 4-12